



Sky Laboratories Kft.
 2146 Mogyoród, Hungary
 Kerekút u. 2
 Pf.: 16
 Tel.: +36-28-542-250
 Fax: +36-28-542-251
 E-mail: sales@skylaboratories.com
 Web: www.skylaboratories.com


Release Note 22 March 2009

DEC (DTMF ethernet converter) IP camera control and extended Inovonics Wireless interface



A great enhancement is made on DEC alarm Mini, CEC alarm mini.
 The new 1.6 version features:

-32 Inovonics wireless devices (instead of 8)



STATUS
CONFIGURE
RF DEVICES
CAMERAS
LOGS
QUIT


Inovonics devices

[Add/remove devices](#)

#	Type	Id	Name
1.	ES1242 - Residential Smoke Detector	3256848	füst
2.	ES1260 - Inovonics PIR	3257350	I_PIR
3.	ES1262 - Bosch PIR	3406118	Bosch PIR
4.	E*1223S - Water Resistant One-Button Pendant	3435405	ON/off
5.	ES1233D - Two-Button Necklace Pendant	3368119	Panic
6.	Disabled	0	
7.	Disabled	0	
8.	Disabled	0	
9.	Disabled	0	
10.	Disabled	0	
11.	Disabled	0	
12.	Disabled	0	
13.	Disabled	0	
14.	Disabled	0	
15.	Disabled	0	

-8 IP camera control (DEC and CEC alarm mini now can control professional buit in memory IP cameras with auto Iris lens. The IP cams could be allocated to zone(s) and those pre and post alarm images which recorded will be sent to ETMS monitoring software or FTP servers. Start and stop recording is controlled by arming/disarming of the unit.

STATUS CONFIGURE RF DEVICES CAMERAS LOGS QUIT



Cameras

Add/remove devices

#	IP address	Name
1.	192.168.4.160	cam1
2.		
3.		
4.		
5.		
6.		
7.		
8.		

You can add cameras here.
 After "APPLY changes", you can assign cameras to inputs under CONFIGURE menu.

Camera(s)

Force capture:

Disabled ▾

Inputs

Input	Device name	I-type	Type	Report disable	Email report	Name	Camera
#1 (local)	-	-	Delayed ▾	<input type="checkbox"/>	<input checked="" type="checkbox"/>	Késleltetett	cam1 ▾
#2 (local)	-	-	Disabled ▾	<input type="checkbox"/>	<input checked="" type="checkbox"/>	Input#2	cam1 ▾
#3 (local)	-	-	Follower ▾	<input type="checkbox"/>	<input checked="" type="checkbox"/>	Követő	cam1 ▾
#4 (local)	-	-	Disabled ▾	<input type="checkbox"/>	<input checked="" type="checkbox"/>	Input#4	cam1 ▾
#5 (local)	-	-	Normal ▾	<input type="checkbox"/>	<input checked="" type="checkbox"/>	Azonnali	cam1 ▾
#6 (local)	-	-	Disabled ▾	<input type="checkbox"/>	<input checked="" type="checkbox"/>	Input#6	cam1 ▾
#7 (local)	-	-	Keysw. Away/Stay ▾	<input type="checkbox"/>	<input checked="" type="checkbox"/>	Kulcsos	cam1 ▾
#8 (local)	-	-	Disabled ▾	<input type="checkbox"/>	<input checked="" type="checkbox"/>	Input#8	cam1 ▾
#9 (external)	füst	Input#1	24H Alarm ▾	<input type="checkbox"/>	<input checked="" type="checkbox"/>	Tűz	cam1 ▾
#10 (external)	I_PIR	Input#1	Normal ▾	<input type="checkbox"/>	<input checked="" type="checkbox"/>	Inovonics PIR	cam1 ▾
#11 (external)	I_PIR	Tamper	24H Alarm ▾	<input type="checkbox"/>	<input checked="" type="checkbox"/>	Ino_pir_tamper	cam1 ▾
#12 (external)	Bosch PIR	Input#1	Normal ▾	<input type="checkbox"/>	<input checked="" type="checkbox"/>	Bosch	cam1 ▾
#13 (external)	Bosch PIR	Tamper	24H Alarm ▾	<input type="checkbox"/>	<input checked="" type="checkbox"/>	Bosch tamper	cam1 ▾
#14 (external)	ON/off	Input#1	Keysw. Away/Stay ▾	<input type="checkbox"/>	<input checked="" type="checkbox"/>	On/Off	Disabled ▾
#15 (external)	Panic	Input#1	24H Alarm ▾	<input type="checkbox"/>	<input checked="" type="checkbox"/>	Panic nyomogomb	cam1 ▾

-Multi user access

Four different user web access granted with selectable access level to view program or interact with DEC and CEC panel. This feature enhancement makes possible to eliminate unauthorized access and change to sections of programming or control of the panel.

-More e-mail address to report

This feature makes possible to send e-mail or transferred e-mail to SMS (TEXT) messages from DEC, CEC ethernet based panels without any further GSM modem.

Arming/Disarming/System and Alarm messages now could be sent to multiply e-mail addresses or forwarded a sSMS (Text message)

-Stay mode arming.

New wireless stay mode arming is available on the latest firmware, making possible to automatically bypass Stay zones with Night Arm only designated keyfobs.